VENTS

The vents are installed in ducts for the extraction of stale air or supply of fresh air. DUCO does not lose sight of the aesthetic or the functional aspect here either.



WHICH VENTS TO CHOOSE?

	DucoVent Basic see p. 66	DucoVent Comfort see p. 66	DucoVent Design see p. 67
Type of DucoBox	DucoBox Energy Comfort DucoBox Energy Premium	DucoBox Energy Comfort DucoBox Energy Premium	DucoBox Energy Comfort DucoBox Energy Premium
Type of vent	Supply Extraction	Supply Extraction	Supply* Extraction * With the exception of 'Standard' vents
Air flow	Up to 75 m³/h	Extraction: up to 75 m³/h Supply: up to 75 m³/h	Extraction: up to 75 m³/h Supply: up to 50 m³/h
Design	*	***	****
Shape	Round	Round	Round Square Standard and XL Rounded Square Standard and XL
Material	Plastic	Plastic (ASA)	Aluminium
Colour	White	White	All RAL
Sound absorption	*	***	****
Ease of maintenance	**	***	****
Fitting	Terminals in DucoFlex	Sealing rubber in DucoFlex	Terminals in DucoFlex
Setting flow rate	Fine adjustment via rotary adjuster	11 adjustable positions	Initial barrier with flow rings + Fine adjustment via rotary adjuster
Price	€	€€	€€€

65